

CHIMNEY FLASHING

1. Prime masonry with MFM Prime-A-Seal® and allow to dry.
2. Install MFM underlayment in order as shown by steps.
3. Extend MFM underlayment from eave to below chimney and from above chimney to ridge.
4. Install MFM underlayment to form water-shedding laps.
5. Apply a continuous bead of compatible sealant along the top termination edge of underlayment on chimney and tool flat.

