

UNDERLAYMENT PIPE PENETRATION

1. Cut fig.1 to size so flanges will extend at least 3” from pipe onto deck. Example: Cut 10” X 10” square, cut circle out for pipe then cut flanges.
2. Cut fig. 2 to size so it covers fig. 1 by at least 2”. Example: Cut 12” X 12” square then cut circle out for pipe.
3. Apply MFM underlayment so water will run over laps.
4. Cut MFM underlayment at pipe penetration so it will extend at least 3” up onto pipe.

